



MODEL 1335 TRANSFER PUMP LEVER ACTION



OWNER/OPERATOR RESPONSIBILITY

It is the owner/operator responsibility to properly use and maintain this equipment.

The instructions and warnings contained in this manual shall be read and understood by the owner/operator prior to operating this equipment.

If an owner/operator does not understand english, the contents of this manual shall be explained in the owner/operator native language to assure the owner/operator comprehends.

It is the owner/operator responsibility to maintain the leg- ©
ibility of all warning and instruction labels.

DESCRIPTION

Suitable to pump diesel fuel, lubricating oils up to SAE 140* and other non-corrosive fluids.

Supplied with 1.8m (6 ft) delivery hose and metal nozzle.

Variable handle setting for light or heavy fluids.

Telescopic suction tube fits 60 liter (16 us gal) and 205 liter (55 us gal) drums. Convenient bung opener cast on pump head.

The owner/operator shall retrain this manual for future reference to important warnings, operating and maintenance instructions.

SPECIFICATIONS

Output approximately .26 quart (250ml)\ stroke.





WARNING

Not for use with gasoline or other flammable liquids.

* @ 70°F

© Indicates change



Handy Bung-Opener on Pump Head




FIG. 1

PARTS REQUIRED

Item	Part	Description
1	273734	Kit, Barrel
2	273735	Kit, Plunger
3	273736	Kit, Handle
4	273737	Kit, Plunger Rod
5	273738	Kit, Packing
6	273739	Kit, Hose




FIG. 2

TROUBLESHOOTING		
TROUBLE	CAUSE	REMEDY
Hard to pump.	A. Gland Nut is screwed down too tight.	A. Adjust Gland Nut.
	B. Handle is positioned in the wrong setting for heavy fluid.	B. Adjust Handle Position (See Fig. 2).
	C. Bent Piston Rod.	Replace Piston Rod and Piston Assembly.
Pump fails to prime.	A. Footvalve ball is not sealing.	A. Remove and clean footvalve. Reassemble the footvalve using Pipe Sealant on Threads.
	B. Piston Valve is damaged and is not seating.	B. Replace Piston and Piston Rod Assembly.
	C. O-Ring is not sealing.	C. Replace O-Ring.

WARNING

FAILURE TO HEED THE FOLLOWING WARNINGS INCLUDING MISUSE, MODIFYING PARTS, USING INCOMPATIBLE CHEMICALS AND FLUIDS, OR USING WORN OR DAMAGED PARTS, MAY RESULT IN EQUIPMENT DAMAGE AND/OR SERIOUS PERSONAL INJURY, FIRE, EXPLOSION, OR PROPERTY DAMAGE.

- Do not alter or modify any part of this equipment.
- Make sure the pump and all other equipment used or Located in the pumping area are grounded.
- Do not use the pump if any static sparking or electrical shock occurs. Stop pumping immediately and do not use the pump until the problem is corrected.
- Make sure all fluid connections are securely tightened before using this equipment.
- Always read and follow the fluid manufacturers recommendations regarding fluid compatibility, and the use of protective clothing and equipment.
- Check all equipment regularly and repair or replace worn or damaged parts immediately.

COMPATIBLE YES or NO			
LIQUID		LIQUID	
ACETONE	NO	GLYCERINE	YES
AMLY ALCOHOL	NO	GLYCOLS	YES
BENZENE	YES	HYDRAULIC OIL (MINERAL)	YES
BENZYL ALCOHOL	YES	ISOBUTYL ALCOHOL	YES
BUNKER OIL	YES	ISO-OCTANE	YES
BUTYL ALCOHOL	YES	ISOPROPYL ALCOHOL	YES
CASTER OIL	YES	KEROSENE	YES
CREOSOTE	YES	LINSEED OIL	YES
CRESOL	YES	LUBRICATING OIL (MINERAL)	YES
CYCLOHEXANE	YES	METHYL ALCOHOL	NO
CYCLOHEXANOL	YES	METHYLBUTYL KETONE	NO
CYCLOHEXANONE	NO	METHYL ETHYL KETONE (MEK)	NO
DENATURED ALCOHOL	YES	METHYL ISOBUTYL KETONE	NO
DETERGENT	YES	MINERAL OIL	YES
DEVELOPING FLUID	YES	MONOCHLOROBENZENE	YES
DIESEL OIL	YES	OCTYL ALCOHOL	YES
DIETHYL BENZENE	YES	PAINT THINNER (DUCO)	YES
DIETHYLENE GLYCOL	YES	PETROL	YES
DI-ISOBUTYLENE	YES	PHENOL	YES
DI-ISOPROPYL BENZENE	YES	PROPYL ALCOHOL	YES
DI-ISOPROPYL KETONE	NO	SILICONE OILS	YES
DIOCTYL PHTHALATE	YES	SOAP SOLUTIONS	YES
DRY CLEANING FLUID	YES	TERTIARY BUTYL ALCOHOL	YES
ETHYL ALCOHOL	YES	TOLUENE	YES
ETHYL BENZENE	YES	TRANSFORMER OIL	YES
ETHYLENE GLYCOL	YES	TRANSMISSION FLUID	YES
FLUOROBENZENE	YES	TRICHLOROETHANE	YES
FLUOROCARBON OILS	NO	TRICHLOROETHYLENE	YES
FLUORINATED CYCLIC ETHERS	NO	TURBINE OIL	YES
FUEL OIL	YES	TURPENTINE	YES

Note: Use of this equipment to pump other than approved fluids can and will void the manufacturer warranty.

Lincoln Industrial Standard Warranty

LIMITED WARRANTY

Lincoln warrants the equipment manufactured and supplied by Lincoln to be free from defects in material and workmanship for a period of one (1) year following the date of purchase, excluding there from any special, extended, or limited warranty published by Lincoln. If equipment is determined to be defective during this warranty period, it will be repaired or replaced, within Lincoln's sole discretion, without charge.

This warranty is conditioned upon the determination of a Lincoln authorized representative that the equipment is defective. To obtain repair or replacement, you must ship the equipment, transportation charges prepaid, with proof of purchase to a Lincoln Authorized Warranty and Service Center within the warranty period.

This warranty is extended to the original retail purchaser only. This warranty does not apply to equipment damaged from accident, overload, abuse, misuse, negligence, faulty installation or abrasive or corrosive material, equipment that has been altered, or equipment repaired by anyone not authorized by Lincoln. This warranty applies only to equipment installed, operated and maintained in strict accordance with the written specifications and recommendations provided by Lincoln or its authorized field personnel.

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

In no event shall Lincoln be liable for incidental or consequential damages. Lincoln's liability for any claim for loss or damages arising out of the sale, resale or use of any Lincoln equipment shall in no event exceed the purchase price. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, therefore the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights that vary by jurisdiction.

Customers not located in the Western Hemisphere or East Asia: Please contact Lincoln GmbH & Co. KG, Walldorf, Germany, for your warranty rights.

Lincoln Industrial Contact Information

To find Lincoln Industrial's Nearest Service Center call the following numbers, or you may also use our website

Customer Service 314-679-4200

Website lincolnindustrial.com

Americas: One Lincoln Way St. Louis, MO 63120-1578 USA Phone +1.314.679.4200 Fax +1.800.424.5359	Europe/Africa: Heinrich-Hertz-Str 2-8 D-69183 Walldorf Germany Phone +49.6227.33.0 Fax +49.6227.33.259	Asia/Pacific: 51 Changi Business Park Central 2 #09-06 The Signature Singapore 486066 Phone +65.6588.0188 Fax +65.6588.3438	© Copyright 2004 Printed in USA Web site: www.lincolnindustrial.com
---	---	---	---
